

To receive the maximum life and use of your Simplex Isolation Systems products, some simple steps should be taken:

STANDARD PVC AND ANTI-STATIC STRIPS / SOFT WALL CURTAINS

Periodically clean using one of the following cleaning compounds:

- Mild dish soap and water solution
- Any biodegradable cleaner

Instructions: Wash the front and back of the strips and or curtains and rinse with clear water then wipe dry with a clean, lint-free soft cloth.

ANTI-STATIC VINYLS

Anti-static vinyls have additive materials that continuously provide a naturally occurring hydro-scopic surface which is essential for the continuation of the anti-static process. Over time and with exposure to the environment the surface will develop a viscous feel. To remove the viscous coating, periodically clean using the following cleaning compounds:

50/50 solution of isopropyl alcohol and Di water

Instructions: Wash the front and back of the strips and or curtains using a soft non-abrasive lint-free cloth.

POLYSIM™ MATERIAL

PolySim[™] is an inherently static dissipative polyurethane product and can be cleaned using any of the above methods.

Instructions: Wash the front and back of the strips and or curtains using a soft non-abrasive lint-free cloth.

POLYCARBONATE, ACRYLIC OR POLYPROPYLENE SHEETS

Periodically clean using one of the following cleaning compounds:

- 20% isopropyl alcohol to 80% Di water mix
- 20% white vinegar to 80% Di water mix
- Window cleaner with vinegar (no ammonia)

Instructions: Wash the front and back of the sheets using a soft non-abrasive lint-free cloth.

ALUMINUM FRAMING AND BARS

Periodically clean using any of the above methods or using one of the following cleaning compounds:

- 20% Simple Green® to 80% water mix
- Any biodegradable cleaner

Note: Simple Green® may leave a white film on clear PVC Polycarbonate and Acrylic, this can be cleaned with a 20% isopropyl alcohol to 80% Di water mix or with a 20% white vinegar to 80% Di water mix).

Instructions: Wash the front and back of the strips and or curtains using a soft non-abrasive lint-free cloth.

Note: Excessive cleaning using harsh or abrasive cleaning compounds such as ammonia, 100% isopropyl alcohol, liquids with chlorinates, anti-fungals, highly active sterile cleaning solutions and dry powder additives are not recommended and will increase the aging process.

We believe the above information to be true and accurate to the best of our knowledge, but cannot Warranty applications and processes beyond our control.



